

## **Application Instructions**

**Handling:** Paint should be stirred and poured gently. Do not mix mechanically.

**Preparation:** For best results make note of the following primer suggestions: For Black Aqua Trunk Paint apply a darker primer before painting. For Grey White Trunk Paint apply a lighter primer before painting.

**Reduction:** None necessary. If thinning is required, water should be added gradually in small increments until an acceptable spray pattern is achieved.

**Application Technique:** A 2 quart pressure pot is needed for best results, 10-25 lbs pressure, hold gun 10-15 inches away to get correct pattern - pattern will change with distance change from surface.

**CleanUp:** Flush equipment with water followed by mineral spirits or flush equipment with lacquer thinner.

**Precautions:** Use with adequate ventilation.

**Dry Time:** Dry to touch, 2 to 4 hours, to use 24 hours, and full cure is 5 to 7 days. Dry time will vary according to temperature, humidity, and film thickness.

\*\* This trunk paint does not require a clear top coat.