

# SUBFRAME BODY MOUNT BUSHING KITS

*Important - Please read this entire document before attempting installation.*

## Kit Contents:

Part #	Qty	Description	Mounting Position
#3893159	(2)	Bushing	#1 Upper
#14008366	(2)	Bushing	#1 Lower
#3928380	(2)	Bushing	#2 Upper
#3914802	(2)	Bushing	#2 Lower
#3901361	(2)	Bushing	#3 Upper
#3914802	(2)	Bushing	#3 Lower

## Manufacturer's Notes:

### Tightening Torque:

Bushings located at radiator support: 40 ft. lbs.

Bushings located at firewall: 95 ft. lbs.

Bushings located at AFT positions: 95 ft. lbs.

Take care to ensure proper alignment of body bushings; improper alignment may cause premature wear.

