

Ford Oxygen Sensor Extensions Installation Instructions



These Instructions Cover the Following Part Numbers:

HE-87	1987-93 Ford Mustang Oxygen Sensor Extension Set
HE-94	1994-95 Ford Mustang Oxygen Sensor Extension Set
HE-96	1996-03 Ford Mustang Oxygen Sensor Extension Set

Installation Instructions:

- 1) Disconnect battery.
- 2) Raise vehicle and secure appropriately.
- 3) Install extensions between oxygen sensor and factory harness.

Complete installation by confirming harness is routed away from exhaust and any moving parts.

Ron Francis Wiring 200 Keystone Rd. Chester, PA 19013 800-292-1940 www.ronfrancis.com

Warranty Information

All Ron Francis wiring products are warranted for 1 year from purchase date. There are no other representations, warranties or conditions expressed or implied, statutory or otherwise except those herein contained. Warranty does not cover any defect which is the result of improper installation or modification of the system or any of its components by purchaser.

Ron Francis wiring, its dealers or agents will not be liable, in any way, for any damage, loss, injury or other claims, resulting from the use or misuse, or inability to use any of our products. Purchaser and/or user, assumes liability of any kind connected with the use and/or application of our products.

Copyright @ 2006 Ron Francis wiring