



Installation

Clean glass thoroughly.

Apply gasket onto glass starting at the corners. Make sure corners and trim are in the right place. For gaskets without corners, make sure you place the vulcanized seam in the bottom middle of the glass.

Insert a 1/4" diameter rope in the section at the bottom of the gasket. Starting at the bottom and overlapping 6 to 8 inches.

Spray the gasket with a soapy water solution to help ease installation.

Lay the glass and gasket into the vehicle opening making sure it is aligned squarely.

Start pulling the rope from the inside of the vehicle working slowly from the top center and finishing at the bottom with the rope. Gently pat the glass into place with a flat hand from the outside.