



1988 Ford Truck
Injector Harness
Installation Instructions



*product may vary from photo.

These Instructions Cover the Following Part Numbers:

FH-I302 1988 Ford Truck with 302 & 351 Engine Injector Harness

Installation Instructions:

- 1) Disconnect battery
- 2) Begin removing the existing injector harness by disconnecting the harness from the main harness and at the sensors. Note how harness is routed.
- 3) Install replacement harness following factory routing.
- 4) Complete installation by confirming harness is routed away from exhaust and any moving parts.

Wire Works Enterprises Inc
T/A Ron Francis Wiring
200 Keystone Rd.
Chester, PA 19013
877-968-7842
www.ronfrancis.com

Warranty Information

All Ron Francis Wiring products are warranted for 1 year from purchase date. There are no other representations, warranties or conditions expressed or implied, statutory or otherwise except those herein contained. Warranty does not cover any defect which is the result of improper installation or modification of the system or any of its components by purchaser.

Ron Francis Wiring, its dealers or agents will not be liable, in any way, for any damage, loss, injury or other claims, resulting from the use or misuse, or inability to use any of our products. Purchaser and/or user, assumes liability of any kind connected with the use and/or application of our products.

Copyright © 2006 Ron Francis Wiring.