
# INSTRUCTION SHEET CARTER CARBURETOR — MODEL YFA

REF.

#### GENERAL EXPLODED VIEW

THE GENERAL DESIGN AND PARTS SHOWN WILL VARY TO INDIVIDUAL UNITS COVERED ON THIS INSTRUCTION SHEET.



#### DISASSEMBLY

USE EXPLODED VIEW AS A GUIDE. THE NUMERICAL SEQUENCE MAY GENERALLY BE FOLLOWED TO DISASSEMBLE UNIT FAR ENOUGH TO PERMIT CLEANING AND INSPECTION. NOTE: TO REMOVE PLASTIC LIMITER CAP (52) INSTALL A SHEET METAL SCREW IN THE CENTER OF THE CAP AND TURN CLOCKWISE.

#### NOMENCLATURE

REF.

NO.		NO.	
1.	SCREW & LOCKWASHER(2)- SOLENOID BRACKET		LEVER-VENT STOP LEVER-OPERATING
	LOCKNUT-BRACKET SCREW	29.	SPRING WASHER-OPERATING
	SOLENOID & BRACKET ASSY.		LEVER
4.	SCREW(3)-CHOKE COVER CLAMP	30.	E CLIP-SPRING WASHER RETAINER
5.	RETAINER CLAMP-CHOKE	31.	ARM-PUMP LINK
-	COVER	32.	LINK-PUMP CONNECTOR
6.	CHOKE COVER & SPRING		JET-LOW SPEED
	ASSY.		RETAINER-UPPER PUMP
7.	GASKET-CHOKE COVER	l	SPRING
8.	BAFFLE PLATE-CHOKE	35.	SPRING-UPPER PUMP
9.	RETAINER-FAST IDLE ROD	36.	ARM & ADJ. SCREW ASSY
10.	ROD-FAST IDLE		METERING ROD
11.	SCREW & LOCKWASHER(2)-	37.	ROD-METER ING
	BOWL COVER	38.	PLATE-ADJ. SCREW
12.	SCREW & LOCKWASHER(3)-	39.	LINK-PUMP LIFTER
	BOWL COVER	40.	SCREW & LOCKWASHER(4)-
13.	BOWL COVER ASSY.		PUMP HOUSING
14.	PIN-FLOAT	41.	PUMP HOUSING ASSY.
15.	FLOAT & LEVER ASSY.		RETAINER-PUMP SPRING
16.	NEEDLE, SEAT & GASKET	43.	SPRING-PUMP RETURN
	ASSY.	44.	PUMP DIAPHRAGM ASSY.
17.	SCREEN-NEEDLE SEAT	45.	SPACER-PUMP DIAPHRAGM
18.	RETAINER-VENT VALVE	46.	TUBE-PUMP PASSAGE
	SHAFT	47.	JET-MAIN
	SHAFT-VENT VALVE	48.	SCREW(4)-THROTTLE BODY
	SPRING-VENT SHAFT	49.	BOWL ASSY.
	LEVER-VENT VALVE	50.	CAP-PIPE
	VALVE-VENT	51.	GASKET-THROTTLE BODY
	GASKET-BOWL COVER	52.	CAP-IDLE LIMITER
	WEIGHT-DISC. BALL		NEEDLE-IDLE ADJUSTING
	BALL-PUMP DISC. CHECK	54.	SPRING-IDLE NEEDLE
26.	SCREW-VENT OPERATING LEVER STOP	55.	THROTTLE BODY ASSY.

#### CLEANING

CLEANING MUST BE DONE WITH CARBURETOR DISASSEMBLED. USE A CARBURETOR CLEANING SOLVENT TO SOAK PARTS LONG ENOUGH TO SOFTEN AMD REMOVE ALL FOREIGN MATERIAL. MAKE CERTAIN THE THROTTLE BORE IS FREE OF ALL CARBON AND VARNISH DEPOSITS. RINSE OFF IN SUITABLE SOLVENT. BLOW OUT ALL PASSAGES IN CASTINGS WITH COMPRESSED AIR AND CHECK CAREFULLY TO INSURE THOROUGH CLEANING OF OBSCURE AREAS. CAUTION: DO NOT SOAK PARTS CONTAINING RUBBER MATERIALS. SUCH AS (3)(6)(22)(44)

#### REASSEMBLY

REASSEMBLE IN REVERSE ORDER OF DISASSEMBLY. NOTE: SPECIAL INSTRUCTIONS AND FOLLOW NUMERICAL OUTLINE IN MAKING ADJUST-MENTS NECESSARY FOR CARBURETOR BEING SERVICED.


#### SPECIAL INSTRUCTIONS


IDLE ADJUSTING NEEDLE (53)-TURN IN UNTIL LIGHTLY SEATED, THEN BACK OUT I 1/2 TURNS. (DO NOT INSTALL LIMITER CAP AT THIS TIME.)


PUMP DIAPHRAGM INSTALLATION (44)-INSERT DIAPHRAGM (44) IN HOUSING (41) AND ALIGN HOLES. INSERT SCREWS THROUGH HOUSING AND DIAPHRAGM. INSTALL SPRING (43) AND RETAINER (42). PLACE IN CARBURETOR START SCREWS THEN COMPRESS DIAPHRAGM, HOLDING IN THIS POSITION TIGHTEN SCREWS.


FLOAT PIN (14)-INSTALL WITH SHOULDER ON PIN AWAY FROM PUMP DIAPHRAGM STEM.


### **ADJUSTMENTS**





























## ADJUSTMENT DATA TABLE

YEAR	APPLICATION FORD PRODUCTS	DRY FLOAT LEVEL	FAST IDLE CAM	CHOKE VALVE PULLDOWN	UNLOADER	AUTO CHOKE SETTING	CURB IDLE R.P.M.	FAST IDLE R.P.M.
1975	PASS CAR 200" ENG. A/T M/T	3/8" ×	.140	.290 .290	.250 .250	INDEX INDEX	E/D E/D	2000 1750
1975	PASS CAR 250" ENG. ALL/T CARB. NO. D5DE-EA,EB M/T	3/8" × 3/8" ×	.140 .140	.290 .230	.250 .250	2-RICH 2-RICH	E/D E/D	1700 1700
1976	PASS CAR 200" ENG. A/T M/T	25/32" 25/32"	.140	.260 .260	.250 .250	2-RICH 1-RICH	E/D E/D	1700 1700
1976	PASS CAR 250" ENG. A/T CARB. NO. D6DE-CA A/T CARB. NO. D6DE-DA A/T M/T	25/32" 25/32" 23/32" 25/32"	.140 .140 .140 .140	.230 .260 .290 .290	.250 .250 .250 .250	INDEX INDEX 2-RICH INDEX	E/D E/D E/D E/D	1700 1700 1700 1700
1976	PASS CAR 250" ENG. CALIF. ALL/T	23/32	.140	.290.	.250	2-RICH	E/D	1700
1977	PASS CAR 200" ENG. A/T M/T	25/32" 25/32"	.140	.260 .290	.250 .250	2-RICH INDEX	E/D E/D	1700 1700
	PASS CAR 250" ENG. A/T CALIF. A/T CAN. A/T FED. M/T	25/32" 25/32" 23/32" 25/32"	.140 .140 .140 .140	.260 .290 .290 .290	. 250 . 250 . 250 . 250	1-RICH 2-RICH 2-RICH INDEX	E/D E/D E/D E/D	E/D E/D E/Q E/D
	TRUCK 300" ENG. ALL/T	25/32"	.110	.290	.280	INDEX	E/D	E/D

E/D = ENGINE DECAL # = LATE TYPE (TAPERED FLOAT) 23/32"